

Mobolink

Software

Mobolink dashboard column ICCID stand for what?

1. ICCID is SIM card's unique ID
2. Not show ICCID : mean SIM card is not installed.

How to configure volume from StageGo?

Please refer to below procedure

http://a2401.s3.amazonaws.com/cs/app/StageGo/Select_Full_Managed_in_Audio%E2%80%93Adjust_volume.docx

