

TB110

HW

In TB110, How much the maximum capacity of the micro SD Card

Reader can be supported?

The maximum capacity of the micro SD Card Reader is 128GB.

How many Indicator LED of TB110 & how to works?

3 LED (Battery, Power, Front camera)

Battery: Charging state red light, full of light out

Power: Green light for system startup status

Front camera: The front camera work lights up white

In TB110, How to close the camera function?

- 1. Connect a USB keyboard to the TB110.
- 2. Power on TB110 and press the delete button on the keyboard.
- 3. Entry to the BIOS setting interface, please follows the below setting:

Advanced→ Others→ Camera→Disabled.

4. Press the F4 button (Save & Exit) of the keyboard → press Yes





OS

How to auto power on TB110 without press the power button when

TB110 inside the kiosk?

- 1. Connect a USB keyboard to the TB110.
- 2. Power on TB110 and press the delete button on the keyboard.
- 3. Entry to the BIOS setting interface, please follows the below setting:

Advanced→ Others→ AC automatic Power On→ Change Disabled to Enabled.

4. Press the F4 button (Save & Exit) of the keyboard → press Yes

How to know the O.S version of TB110?

Settings-System-About-Windows specifications

How to reset TB110?

Settings→update & Security→Recovery→Reset this PC

How to Restore Hard Disk Image on TB110?

Please follow the SOP to restore the O.S and download the O.S from the below link:

http://download1.tw.ute.com/cs/firmware/TB110/TB110 Restore HDI SOP 20210616.pdf

http://download1.tw.ute.com/cs/firmware/TB110/E7251U1 loT RS5 EN TW R.FD.00.52.04 20210423.zip

In TB110, What is the end-of-life support date of O.S Windows 10?

Windows 10 Enterprise: Active & Security support to 14 Oct 2025. Please refer to the below URL:

https://endoflife.date/windows



Software

Does the TB110 have SDK and a programming manual for the

customer to reference?

TB110 is a tablet based on Intel X86 + Win10. The Programming and SDK all follow Microsoft standards.

Please refer to the below URL:

https://developer.microsoft.com/en-us/windows/downloads/sdk-archive/