

# MS912+

## Decoder

### How to set the Field separator?

1. Scan [.M005\$] in UM Pg 72
2. Scan [.M007\$] DEFINE EAN128 in UM Pg 72
3. Scan [+] + from the full ASCII table. in UM Pg 77
4. Scan [.M007\$] DEFINE EAN128 in UM Pg 72

## FW

### How to set the MS912plus pin code?

By default, the pincode under SPP profile for the scanner is “1234”, please refer to MS912plus user manual in chapter 4.2.2.4 to customize this pincode, if you need.

